


7400 tennant manual



File Name: 7400 tennant manual.pdf

Size: 2459 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 22 May 2019, 16:50 PM

Rating: 4.6/5 from 554 votes.

Download Now!

Please check the box below to proceed.




I'm not a robot



reCAPTCHA
Privacy - Terms

Book Descriptions:

7400 tennant manual




Please try again later. Or, for some documents, you can purchase a professionally printed copy by selecting the Add to cart link on the right, then selecting checkout. The prices will be available upon checkout. Electrical Battery maintenance and replacement, instrument panel replacement, and electrical troubleshooting. Manual Number MM 428 Revision 04 Published 3 02 CALIFORNIA PROPOSITION 65 WARNING Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Copyright © 1996, 1998, 2001, 2002 TENNANT, Printed in U.S. A. FOR SAFETY To identify actions which must be followed for safe operation of equipment. The machine is suited to sweep disposable debris. Do not use the machine other than described in this Operator Manual. The machine is not designed for use on public roads. Do not wear loose jackets, shirts, or sleeves. Block machine tires before jacking machine up. Jack machine up at designated locations only. Block machine up with jack stands. Use hoist or jack of adequate capacity to lift machine. Wear eye and ear protection when using pressurized air or water. Disconnect battery connections before working on machine. Avoid contact with battery acid. Avoid contact with hot engine coolant. Allow engine to cool. Keep flames and sparks away from fuel system service area. Keep area well ventilated. Use cardboard to locate leaking hydraulic fluid under pressure. Use Tennant supplied or approved replacement parts. WARNING Engine emits toxic gases. Severe respiratory damage or asphyxiation can result. Provide adequate ventilation. Consult with your regulatory authorities for exposure limits. Keep engine properly tuned. WARNING Flammable materials can cause an explosion or fire.

re. <http://agendatourvietnam.com/hinhanh/elks-lodge-ritual-manual.xml>

- **7400 tennant manual, tennant 7400 parts manual, tennant 7400 scrubber parts manual, tennant 7400 service manual, tennant 7400 operator manual, tennant 7400 parts manual pdf, tennant 7400 scrubber manual, tennant 7400 maintenance manual, tennant 7400 floor scrubber manual, 7400 tennant manual, 7400 tennant parts manual, 7400 tennant sweeper service manual.**

GENERAL INFORMATION

MAINTENANCE



MAINTENANCE CHART / G.L.P

Interval	Key	Description	Procedure	Lubricant/ Fluid	No. of Service Points	
Daily	4	Engine air filter	Check indicator Empty dust cap	-	1	
	4	Engine crankcase	Check oil level	EO	1	
	8	Rear Squeegee	Check for damage and wear Check deflection	-	1	
	11	Side Squeegees	Check for damage and wear	-	2	
	10	Scrub brushes	Check for damage and wear	-	1	
	7	Recovery tank	Clean	-	1	
	7	Recovery tank, EG™ mode	Clean EG™ filter	-	1	
	5	Solution tank, EG™ mode	Clean	-	1	
	50 Hours	10	Scrub brushes	Rotate end-for-end or front-to-rear	-	1
	100 Hours	6	Radiator	Clean core exterior Check coolant level	WG	1
	4	Engine crankcase	Change oil and filter element	EO	1	
	13	Cover seals	Check for damage and wear	-	4	
	4	Engine	Check fan belt tension Check and adjust idle speed Check and adjust idle mixture	-	1	
	3	Hydraulic fluid reservoir	Check fluid level	HYDO	1	
	-	Tires	Check for damage	-	3	
	8	Rear squeegee	Check leveling	-	1	
	8	Rear squeegee casters	Lubricate	SPL	2	


1-10



7400 MM428 (8-01)

Do not use flammable materials in tanks. WARNING Flammable materials or reactive metals can cause explosion or fire. Do not pick up. WARNING Moving belt and fan. Keep away. WARNING Strong Vacuum. Keep Away From Fan Inlet When Fan Is Running. If these or any labels become damaged or illegible, install a new label in its place. Clean PCV hoses, tubes, and fittings Fuel filter, gasoline 1 800 Hours 3 Hydraulic reservoir Replace filler cap 1 y Replace suction strainer 1 Change hydraulic fluid HYDO 1 4 Hydraulic fluid filter Change filter element 1 Hydraulic hoses Check for wear and damage All 6 Cooling system Flush WG 1 1 Propelling motor HT orque shaft nut 1 1 Front wheel HT orque wheel nuts 1 12 Battery H Clean and tighten battery cable 1 y g y connections NOT E Also check procedures indicated H after the first 50 hours of operation. NOT E More frequent intervals may be required in extremely dusty conditions. HYDO Tennant or approved hydraulic fluid. SPL Special lubricant, Lubriplate EMB grease TENNANT part no. 01433 1. DW Distilled water. NOT E More frequent intervals may be required in extremely dusty conditions. HYDO Tennant Company or approved hydraulic fluid. SPL Special lubricant, Lubriplate EMB grease TENNANT part no. 01433 1. DW Distilled water. The propelling pump has a bypass valve to prevent damage to the hydraulic system when the machine is being pushed or towed. ATTENTION! Do not push or tow machine for a long distance and without using the bypass valve, or the machine hydraulic system may be damaged. The illustration shows the bypass valve in the pushing or towing position. If the loading surface is horizontal AND is 380 mm 15 in or less from the ground, the machine may be driven onto the truck or trailer.

3. <http://cjsayles.com/~cjsayles/images/elks-soccer-shoot-manual.xml>




To winch the machine onto the truck or trailer, attach the winching chains in the holes at the bottom of the rear bumper. See PUSHING OR TOWING THE MACHINE section of this manual. Make sure the machine is centered. FOR SAFETY When loading machine onto truck or trailer, use winch. Do not drive the machine onto the truck or trailer unless the loading surface is horizontal AND is 380 mm 15 in or less from the ground. If the machine starts to veer off the centerline of the truck or trailer, stop and turn the steering wheel to center the machine. 6. Set the parking brake and block the machine tires. Tie down the machine to the truck or trailer before transporting. The front tie down locations are in the holes at the bottom of the front bumper. If the machine has the optional tie down brackets, use them to tie down the machine. The rear tie down locations are in the holes at the bottom of the rear bumper. If the machine has the optional rear tie down brackets, use them to tie down the machine. 7. If the loading surface is not horizontal or is higher than 380 mm 15 in from the ground, use a winch to unload machine. If the loading surface is horizontal AND is 380 mm 15 in or less from the ground, the machine may be driven off the truck or trailer. FOR SAFETY When unloading machine off truck or trailer, use winch. Do not drive the machine off the truck or trailer unless the loading surface is horizontal AND 380 mm 15 in or less from the ground. You can jack up the machine for service at the designated locations. Use a hoist or jack that will support the weight of the machine. Always stop the machine on a flat, level surface and block the tires before jacking the machine up. FOR SAFETY Before leaving or servicing machine; stop on level surface, set parking brake, turn off machine and remove key.

The front jacking location is the left front corner of the machine frame. The rear jacking locations are the two rear corners of the machine frame. FOR SAFETY When servicing machine, block machine tires before jacking machine up. FOR SAFETY When servicing machine, jack machine up at designated locations only. Block machine up with jack stands. Decrease the specified torque by 20% when using a thread lubricant. Do not substitute lower grade hardware for higher grade hardware. Exceptions to the above chart Check the machine for exceptions. BOLT IDENTIFICATION Identification Grade Marking Specification and Grade SAE Grade 5 SAE Grade 8 ISO Grade 8. 8 ISO Grade 10. 9 01395 THREAD SEALANT AND LOCKING COMPOUNDS Thread sealants and locking compounds may be used on this machine. They include the following Locktite 515 sealant gasket forming material. TENNANT Part No. 75567, 15 oz 440 ml cartridge. Locktite 242 blue medium strength thread locking compound. TENNANT Part No. 32676, 0.5 ml tube. Locktite 271 red high strength thread locking compound. TENNANT Part No. 19857, 0.5 ml tube. TO REMOVE SEAT ASSEMBLY FOR SAFETY Before Leaving Or Servicing Machine; Stop On Level Surface, Set Parking Brake, Turn Off Machine And Remove Key. 1. Tilt the seat assembly forward and engage the sprocket. 2. Remove the four hex screws and nuts holding the seat assembly hinge to the seat support. 3. Slide the prop rod to the opening in

the slot and remove. 4. Remove the seat assembly from the machine. TO REPLACE SEAT ASSEMBLY FOR SAFETY Before Leaving Or Servicing Machine; Stop On Level Surface, Set Parking Brake, Turn Off Machine And Remove Key. 1. Position the seat assembly on the seat support. 2. Reinstall all the four hex screws and nuts. Tighten to 18 24Nm 15 20 ft lb. 3.

GENERAL INFORMATION

MAINTENANCE



MAINTENANCE CHART / G/LP

Interval	Key	Description	Procedure	Lubricant/ Fluid	No. of Service Points	
Daily	4	Engine air filter	Check indicator Empty dust cap	-	1	
	4	Engine crankcase	Check oil level	EO	1	
	8	Rear Squeegee	Check for damage and wear	-	1	
	11	Side Squeegees	Check deflection	-	1	
	10	Scrub brushes	Check for damage and wear	-	1	
	7	Recovery tank	Clean	-	1	
	7	Recovery tank, EG™ mode	Clean EG™ filter	-	1	
	5	Solution tank, EG™ mode	Clean	-	1	
	50 Hours	10	Scrub brushes	Rotate end-for-end or front-to-rear	-	1
	100 Hours	6	Radiator	Clean core exterior	-	1
4		Engine crankcase	Check coolant level	WG	1	
13		Cover seals	Change oil and filter element	EO	1	
13		Cover seals	Check for damage and wear	-	4	
4		Engine	Check fan belt tension	-	1	
4		Engine	Check and adjust idle speed	-	1	
4		Engine	Check and adjust idle mixture	-	1	
3		Hydraulic fluid reservoir	Check fluid level	HYDO	1	
-		Tires	Check for damage	-	3	
8		Rear squeegee	Check leveling	-	1	
8	Rear squeegee casters	Lubricate	SPL	2		


1-10

<https://events.citeve.pt/chat-conversation/bose-lifestyle-8-series-ii-manual>

Slide the seat prop rod through large hole in slot. 4. Lower the seat. Adjust Pull the lever out, slide the seat backward or forward to the desired position and release the lever. Lift Pull up on the seat mounting plate until the seat mount locks up. Lower Pull on the release lever and lower the seat mounting plate. STATIC DRAG CHAIN A static drag chain prevents the buildup of static electricity in the machine. The chain is attached to the machine with a hex screw by the scrub head torque tube mount bearing. Make sure the chain is touching the floor at all times. The brakes are operated by the foot brake pedal. Check the brake adjustment every 200 hours of operation. TO REPLACE BRAKE SHOES FOR SAFETY Before Leaving Or Servicing Machine; Stop On Level Surface, Set Parking Brake, Turn Off Machine And Remove Key. 1. Drain the solution and recovery tanks. 2. Make sure the parking brake is not engaged. 3. Remove floor plate from the operators compartment. 4. Loosen the jam nuts on the brake cable turn buckle. Rotate the turn buckle to loosen the tension on the brake cable. 5. Jack up one rear corner of the machine. Place jack stands under machine. FOR SAFETY Block machine tires before jacking machine up. Jack machine up at designated locations only. Block machine up with jack stands. 6. Remove the hub cap from the center of the tire and wheel assembly. 7. Remove the cotter pin, slot nut, flat washer, and bearing cone. 8. Remove the tire and wheel assembly from the machine. 9. Remove the two springs holding the brake shoes together. Remove the old brake shoes. 10. Position the new brake shoes on the brake mounting plate. 11. Reattach the two brake springs to the new brake shoes. The tire should spin freely. 12. Reinstall the hub cap in the center of the wheel. 13. Lower the machine. NOTE Always replace brake shoes in sets.

GENERAL INFORMATION

MAINTENANCE



MAINTENANCE CHART / G.L.P


Interval	Key	Description	Procedure	Lubricant/ Fluid	No. of Service Points
Daily	4	Engine air filter	Check indicator Empty dust cap	-	1
	4	Engine crankcase	Check oil level	EO	1
	8	Rear Squeegee	Check for damage and wear Check deflection	-	1
	11	Side Squeegees	Check for damage and wear	-	2
	10	Scrub brushes	Check for damage and wear	-	1
	7	Recovery tank	Clean	-	1
	7	Recovery tank, EG™ mode	Clean EG™ filter	-	1
	5	Solution tank, EG™ mode	Clean	-	1
50 Hours	10	Scrub brushes	Rotate end-for-end or front-to-rear	-	1
100 Hours	6	Radiator	Clean core exterior	-	1
	4	Engine crankcase	Check coolant level	WG	1
	4	Engine crankcase	Change oil and filter element	EO	1
	13	Cover seals	Check for damage and wear	-	4
	4	Engine	Check fan belt tension	-	1
	4	Engine	Check and adjust idle speed	-	1
	4	Engine	Check and adjust idle mixture	-	1
	3	Hydraulic fluid reservoir	Check fluid level	HYDO	1
	-	Tires	Check for damage	-	3
	8	Rear squeegee	Check levelling	-	1
8	Rear squeegee casters	Lubricate	SPL	2	

1-10

7400 M9428 (8-01)



20. Repeat the procedure on the other wheel. 21. Rotate the brake cable turn buckle until the brake cable is tight or until the brake pedal travels 25 50 mm (1 2 in) before engaging brakes. 22. Tighten the brake cable turn buckle jam nuts. 23. Reinstall the floor plate in the operators compartment. 24. Operate the machine and check the brakes for proper operation. Inspect the rear wheel bearings for seal damage, and repack and adjust every 1600 hours of operation. Use Lubriplate EMB grease T ENNANT part no. 01433 1. TO REPAIR REAR WHEEL BEARINGS FOR SAFE TY Before Leavin g O r Servicing M achi ne; Sto p On L evel Surf ace, Set Parkin g Brake, Tu rn Off Mach ine An d Remo ve Key. 1. Drain the solution and recovery tanks. 2. Make sure the parking brake is not engaged. 3. Remove floor plate from the operators compartment. 4. Loosen the jam nuts on the brake cable turn buckle. Block machine up with jack stands. 6. Remove the hub cap from the center of the tire and wheel assembly. 7. Remove the cotter pin, slotted nut, flat washer, and bearing cone. 8. Remove the tire and wheel assembly from the machine. 9. Pack the wheel bearings with Lubriplate EMB grease. 10. Slide the tire and wheel assembly on the axle. 11. Slide the outer bearing, flat washer and nut on the shaft. The tire should spin freely. 15. Reinstall the hub cap in the center of the wheel. 16. Lower the machine. 17. Repeat the procedure on the other wheel. 18. Rotate the brake cable turn buckle until the brake cable is tight or until the brake pedal travels 25 50 mm (1 2 in) before engaging brakes. 19. Tighten the brake cable turn buckle jam nuts. 20. Reinstall the floor plate in the operators compartment. 21. Operate the machine and check the rear wheels for proper operation. The support has one grease fitting for the bearings.



The front wheel support bearings must be lubricated every 200 hours of operation. Use Lubriplate EMB grease TENNANT part no. 01433 1. Torque the front wheel nuts to 142 156 Nm 105 1 15 ft lb after the first 50 hours of operation, and every 800 hours thereafter. Torque the front wheel hub nut to 375 ft lb TO REPLACE FRONT DRIVE MOTOR FOR SAFETY Before Leaving Operator Seating Machine; Stop On Level Surface, Set Parking Brake, Turn Off Machine And Remove Key. 1. Engage parking brake, block rear tires. 2. Jack up front of machine. Use jack stands to support machine. FOR SAFETY Block machine tires before jacking machine up. Jack machine up at designated locations only. Block machine up with jack stands. 3. Remove the front tire and wheel assembly. 4. Remove the cotter pin and slotted nut from the front wheel drive motor shaft. 5. Use a puller to remove the drive hub from the tapered shaft of the drive motor. 6. Remove and plug the hydraulic hoses leading to the front wheel drive motor. NOTE Observe hydraulic cleanliness requirements when opening hydraulic lines. 7. Remove the four drive motor mounting bolts. 8. Slide the motor out of front wheel housing. Note the orientation of the motor. 11. Reinstall the four socket head screws. Torque to 90 1 17 Nm 70 85 ft lb. 12. Reconnect the hydraulic hoses to the drive motor. NOTE Make sure the square key is in place on the shaft of the new motor. 13. Mount the drive hub to tapered motor shaft. Tighten slotted nut to 500 Nm 375 ft lb. Install the cotter pin. 14. Install the front tire. Torque the front wheel nuts to 142 156 Nm 105 1 15 ft lb. 15. Remove jack stands and lower machine. 16. Operate the machine and check the front drive motor for any leaks. Use jack stands to support machine. Block machine up with jack stands. 4. Remove the front tire and wheel assembly.

5. Remove and plug the hydraulic hoses leading to the front wheel drive motor. Retain the spacer. 8. Remove the cotter pin and large slotted nut from the top of the pivot pin. 9. Loosen the two M10 socket head bolts holding the pivot pin to the machine frame. NOTE Use a floor jack to support the wheel housing before removing the pivot pin. The wheel housing and drive motor assembly is very heavy. 10. Remove the pivot pin from the bottom of the wheel support. NOTE Do not lose the thrust washer from on top of the wheel housing. 11. Remove the wheel housing and drive motor assembly out of the main frame. 12. Use a steel punch and hammer to drive the old bearing cups out of the wheel housing. Use a large press or a punch and hammer to install the cups. 14. Pack the new bearing cones with Lubriplate EMB grease. Coat the bearing cups with grease. 15. Position the new bearing cones in the wheel housing. 16. Position the thrust washer on top of the upper bearing cone. 17. Position the wheel housing back in the machine. 18. Slide the large pivot pin up through hole in the machine frame. Thread castle nut on the top of the pivot pin. Tighten to 34 40 Nm 25 30 ft lb. Check the wheel housing for play. If pin is not seated, tap with rubber mallet and re-torque castle nut. NOTE The wheel housing should rotate with a slight amount of drag. 19. Torque the top socket screw with a hand torque wrench to 100 1 15 Nm 73 85 ft lb. 20. Tighten the castle nut to the next slot and insert the cotter pin. Torque not t

o exceed 100 Nm 75 f t lb. 21. Check t he cast ing to see if it rock s or binds. T ight en to 270 300 Nm 200 220 f t lb. T ighten M 8 hex scr ews to 18.5 24Nm 15 20 ft lb. 26. Inst all the f ront tir e. T orque t he fr ont wheel nuts t o 142 156 Nm 105 1 15 ft lb 27. Re c onnect batt ery cables, s tart engine, run propelling in bot h directions, chec k for leaks.

<http://www.bestlifepolicy.co.uk/wp-content/plugins/formcraft/file-upload/server/content/files/162748e16e85d6--brother-dcp-7055-service-manual.pdf>

28. Remove jac k stands, lower m achine to t he ground. The br ushes scr ub the floor. As t he machine is m oved for ward the squeegee wipes the dir ty s olution off t he floor, which is t hen picked up and drawn int o the recov ery tank by t he vacuum f an. T here are t hree sett ings on t he solution f low high, low, and off. T here is a LH and a RH soluti on tank. They are connec ted by a lar ge diamet er solution line. TO RE MOVE LH SOLU TION T AN K FO R SAFE TY Befo re Leavin g O r Servi ci ng M achi ne; Sto p On L evel Surf ace, Set Parkin g Brake, T u rn Off Mach ine An d Remo ve Key. 1. Empt y t he solution and r ecovery t anks. 2. Open t he engine side door and engine cover. 3. Unlatch the rear radiat or cover panel and tilt it open. 4. Disconnect t he wires going to t he float switc h at t he back of the LH s olution tank. 5. Remove t he two hex scr ews fr om the rear tank brack et where it att aches t o the LH soluti on tank. 6. Remove t he one hex sc rew fr om the rear, lower corner of t he LH t ank. T his hex screw is locat ed near the lef t hand t ailight. 7. Go t o the f ront of t he LH solution t ank. Disconnect the s olution cr oss ov er line fr om the bot tom, f ront of t he LH solution t ank. NOTE Access t he the cl amp on the cross over line is made eas ier by remov ing the t wo vacuum hoses leading t o the rec overy t ank. 8. Remove t he two M 8 hex screws fr om the fr ont of t he LH soluti on tank near t he engine alter nator. 9. The LH s olution t ank can now be lif ted up and out of the m achine fr ame. NOT E B e caref ul not to pinc h hydraulic hos es or electr ical wires during this pr ocedure. 2. Reinst all the t wo M8 hex sc rews in the f ront of t he LH solution t ank near t he engine alter nator. Leav e hardware loose f or now. 3. Reinst all the t wo M8 hex sc rews in the t op, rear of t he LH solution t ank in the rear tank brack et. Leav e hardware loose f or now. 4.

annasteen.com/ckfinder/userfiles/files/compaq-nw9440-manual.pdf

Reinst all the one M8 hex scr ew in the rear, bott om of t he LH soluti on tank near the LH taillight. 5. T ighten t he fiv e M8 hex sc rews to 18 24 Nm 15 20 ft lb. 6. Reconnect t he solution c ross over line at the bot tom of t he tank. NOT E Reconnect t he vacuum hoses if removed earlier. 7. Reconnect t he wires t o the float switc h at the bac k of t he LH solution t ank. 8. Close the rear r adiator cov er panel and latch. 9. Close t he engine side door and engine cover. 10. Fill t he LH solution t ank wit h water and check f or leaks. See TO REM OVE LH SOLUT IO N T ANK and TO REM OVE RECOV ERY T ANK inst ruct ions. 2. Remove t he one hex sc rew fr om the rear, lower corner of t he RH t ank. T his hex screw is locat ed under the f rame, above t he drain cap. 3. Place t he operat ors seat in the r aised position and engage t he prop rod. 4. Remove t he two M 8 hex screws fr om the fr ont, right cor ner of the RH solution tank where it att aches t o the seat suppor t. 5. Disconnect any s olution lines st ill att ached t o the RH s olution tank. 6. The RH s olution t ank can now be lif ted up and out of the m achine fr ame. NOT E B e caref ul not to pinc h hydraulic hos es or electr ical wires during this pr ocedure. 2. Reinst all the one M8 hex scr ew in the rear, bott om of t he RH soluti on tank. T his hex scr ew is located under the f rame, above t he drain cap. Leave har dware loose f or now. 3. Reinst all the t wo M8 hex sc rews fr om the fr ont, right cor ner of the RH solution tank where it att aches t o the seat suppor t. Leave hardware loos e f or now. 4. Reconnect any soluti on lines that wer e disconnect ed fr om the RH s olution t ank. 5. The r emain RH soluti on tank har dware will be installed dur ing the rec overy t ank installat ion. S ee TO INST ALL RECO V ERY T AN K and T O INST ALL LH S OLU TION T ANK ins truc tions.

TO REMO VE RECO VER Y T ANK FO R SAFE TY Befo re Leavin g O r Servi ci ng M achi ne; Sto p

On Level Surface, Set Parking Brake, Turn Off Machine And Remove Key. 1. Empty the solution and recovery tanks. 2. Place the operator's seat in the raised position and engage the prop rod. 3. Remove the LH solution tank. See TO REMOVE LH SOLUTION TANK instructions. 4. Disconnect the vacuum and squeegee hoses from the front of the recovery tank. 5. Remove the two hex screws holding the demister cover on the recovery tank. Remove the demister cover. 6. If the machine is equipped with an overhead guard, it must be removed in order to remove the tank lintel. NOTE The engine hood must be supported in the open position before the next step can be completed. 7. Remove the clips on the bottom of the engine hood gas springs. Remove the gas springs from the ball studs on the support channel. 8. Remove the hex screws holding the support channel to the tank lintel and hood lintel. Remove the support channel from the machine. Remove the cover. 11. Remove the hex screws holding the tank lintel to the frame, recovery tank, RH solution tank, and seat support. Remove the lintel from the machine. 12. Mark, disconnect, and plug the three hydraulic hoses leading to the engine fan hydraulic motor. NOTE Observe hydraulic cleanliness requirements when opening hydraulic lines. 13. Disconnect the solution line at the front of the recovery tank if the machine is equipped with the auto fill option. 14. Disconnect the wires leading to the float switch that is located at the front, right corner of the recovery tank. NOTE Machines equipped with ES will have two switches on the float assembly. 15. Disconnect the solution hose at the back of the tank if the machine is equipped with the ES option. 16. Unplug the main electrical harness from the ES pump at the rear of the tank. 17.

Remove the ES pump and cap assembly from the recovery tank. 18. Remove the one hex screw and two nyloc nuts holding the radiator assembly to the back of the recovery tank. Leave the black mount plate attached to the recovery tank. Do not disconnect the hoses from the radiator. Let the radiator assembly lean against the oil cooler. 20. Remove the two M8 hex screws attaching the rear tank bracket to the RH solution tank. 21. Remove the one M8 hex screw under the rear of the tank, just above the drain cap. 22. Carefully push the recovery tank forward, lift it up, and remove it from the machine. NOTE An overhead hoist or two people must be used when positioning the recovery tank back in the machine frame. 1. Position the recovery tank back in the machine frame. NOTE Be careful not to pinch hydraulic hoses or electrical wires during this procedure. 2. Reinstall all the tank lintel in the machine. Reinstall the six M8 hex screws. Leave the hardware loose for now. 3. Reconnect the solution line at the front of the recovery tank if machine is equipped with the auto fill option. 4. Reconnect the float switches at the front of the recovery tank to the main harness. See schematic in the ELECTRICAL section. 5. Carefully pivot the radiator assembly back in position on the rear of the recovery tank. Reinstall the hardware and tighten to 18 24 Nm 15 20 ft lb. 6. Plug the ES pump back in the main harness. See schematic in the ELECTRICAL section. 7. Reinstall all the hardware in the rear tank bracket where it attaches to the RH solution tank. 8. Reinstall all the one M8 hex screw under the rear of the tank, just above the drain cap. 9. Reinstall all the support channel to the tank lintel and hood lintel. Reinstall all the four M8 hex screws. 10. Tighten all the M8 hex screws to 18 24 Nm 15 20 ft lb.

Reinstall all the two clips. 12. Reconnect the hydraulic hoses to the engine fan motor. See schematic in the HYDRAULIC section. NOTE Observe hydraulic cleanliness requirements when opening hydraulic lines. 13. Reinstall the demister cover on the recovery tank. Reinstall all the two M8 hex screws and tighten to 18 24 Nm 15 20 ft lb. 14. Reinstall the LH solution tank. See TO INSTALL LH SOLUTION TANK instructions. 15. Reconnect the two vacuum hoses to the front of the recovery tank. 16. Reinstall the overhead guard if it was removed earlier. 17. Reinstall the tank drain cover to the rear of the tanks. Reinstall all the hardware and tighten to 18 24 Nm 15 20 ft lb. 18. Reinstall the solution and recovery tank drain covers. 19. Partially fill the recovery tank with water and check for any leaks and for proper operation of the float switches. Water from the solution

on tank flows to the center of the scrub head brush wrap and is spread evenly in front of the scrub brushes. TO REPLACE MAIN SCRUB BRUSHES 1. Place the main scrub brushes in the raised position. FOR SAFETY Before Leaving Or Servicing Machine; Stop On Level Surface, Set Parking Brake, Turn Off Machine And Remove Key. 2. Open the RH brush door. 3. Pull back on the front ball joint locking collar on the leveling rod. Remove the leveling rod from the front ball stud. 4. Remove the two hair pins from the brush wrap attachment pins. 5. Remove the M12 hex screw holding the brush idler plate arm to the lift tube. 6. Remove the idler plate and side squeegee assembly from the machine. NOTE Thread the mounting bolt into the idler arm removal hole if you are having trouble removing the idler arm. 7. Pull the two main brushes off the drive plugs. 8. Line up the drive end of the new or rotated brushes with the brush drive plugs.

The cylindrical scrub brushes must be installed with the V pattern on the brushes pointing towards each other. Slide the brushes onto the brush drive plugs. 8. Reinstall the idler plate and side squeegee assembly in the machine. NOTE Lift up on the brush wraps lightly when installing the idler plate in the machine so the attachment pins line up with the holes in the plate. NOTE Apply a small amount of grease to the threads on the bolt and in the tube. 11. Reinstall the two hair pins in the brush wrap attachment pins. 12. Reconnect the front of the leveling rod to the ball stud. 13. Close the RH brush door and operate the machine. Check the main brushes for proper operation. CHECKING AND ADJUSTING SCRUB BRUSH PATTERN 1. Apply chalk, or some other material that will not easily blow away, to a smooth, level floor. 2. Raise the scrub head. Position the scrub head over the chalked area. 3. Set the parking brake. 4. Lower the scrub head for 15 to 20 seconds while keeping the scrub head in one spot in the chalked area. NOTE If chalk or other material is not available, allow the brushes to spin on the floor for two minutes. A polish mark will remain on the floor. 5. Raise the scrub head, release the parking brake, and drive the machine away from the chalked area. 6. Observe the width of the brush pattern. If the brush patterns have parallel sides and are the same width, the brushes do not need taper adjustment. If one or both of the brush patterns are tapered, the scrub head will have to be adjusted to straighten the brush pattern. 10355 10652 Move the scrub head up to decrease the pattern width on that side of the scrub head. Move the scrub head down to increase the pattern width on that side of the scrub head. Tighten the mounting bolts and check the pattern again and readjust if necessary. The brush patterns should be the same width.

If one is narrower than the other, the scrub head needs to be leveled from front to rear. 8. Lengthen or shorten the leveling rods on both sides of the scrub head. Lengthening the rods will increase the rear brush pattern width. Shortening the rods will increase the front brush pattern. 10653 FOR SAFETY Before Leaving Or Servicing Machine; Stop On Level Surface, Set Parking Brake, Turn Off Machine And Remove Key. 2. Open the RH brush door. 3. Pull back on the front ball joint locking collar. Remove the leveling rod from the front ball stud. 4. Remove the two hair pins from the brush wrap attachment pins. 5. Remove the M12 hex screw holding the brush idler plate arm to the lift tube. 6. Remove the idler plate and side squeegee assembly from the machine. NOTE For better access to the shaft and bearings remove the C clip and brush arm from the idler plate. 7. Turn the idler plate and side squeegee assembly over. Remove the cotter pins, castle nuts, and washers from the idler plugs. 8. Use a puller to remove the idler plugs from the tapered shafts. Remove and retain the square key. 9. Remove the retaining rings from both ends of the idler shafts. 10. Use a press to remove the tapered shafts from the idler plate. Push the shafts out toward the direction of the idler plugs. NOTE Use a small amount of heat in the area of the bearings to help break the lock tight loose. 11. Use a press to remove the bearing from the tapered end of the idler shaft. 12. Use a press to remove the bearing from the bearing housing in the idler plate. Discard the old bearings. 13. Use a press to install a new bearing in the bearing housing on the outside of the idler plate. The open face of the bearing points in. The open face of the bearing points in. Reinstall the retaining ring on the tapered shaft

next to the bearing. 15.

<http://www.jfvtransports.com/home/content/bose-lifestyle-8-series-ii-manual>